newline



LAUNDRY GUIDE

WASHING

- 1 Do not over load the machine, this will result in a poor wash.
- 2 Select the correct program on the touch pad.
- **3** Select the correct wash program for the load type and temperature required.
- 4 Start the washing machine.

AFTER WASHING

- 1 Place items into dryer and select the correct drying temperature and time.
- **2 After drying, remove items** from the dryer and iron garments while they are slightly damp.
- 3 Put washed laundry in a clean dry place.
- 4 Keep the machine doors slightly open and keep drums clean.

HOW TO REPLACE A CONTAINER:

- To replace the Vital laundry products, check the remaining level of product in the container.
- 2 If the product is empty, it needs to be replaced with a new container of the same product.
- **3 Use the PPE specified by your employer** and refer to the MSDS sheets of the product.
- **Set a new full replacement** of the product in place next to the empty container.

- **5 Loosen cap** on full container.
- **Remove the cap and tube** from old container.
- **Transfer cap and tube** to the new full container.
- 8 Never mix or add water to any of our products.
- **9 Clean any spills immediately** and rinse with water.
- Wash and dry hands thoroughly after changing container.



For more information call or go to one of our websites.

Newline Anglia
Tel: 01763 262050
web: www.newlineanglia.co.uk

Newline Essex

Tel: 01702 613615 web: www.newlineessex.co.uk